

EQUIPMENT INVOLVED IN IGNITION

HEATING, VENTILATION, AND AIR CONDITIONING

- 111 Air conditioners
- 112 Heat pumps
- 113 Fan
- 114 Humidifier, non-heat producing (Excludes heaters with built-in humidifiers, see 131-132)
- 115 Ionizer
- 116 Dehumidifier, portable
- 117 Evaporative cooler, cooling tower
- 121 Fireplace, masonry
- 122 Fireplace, factory-built
- 123 Fireplace, insert/stove
- 124 Stove, heating
- 125 Chimney connector, vent connector
- 126 Chimney: brick, stone, masonry
- 127 Chimney: metal (Includes stovepipes and flues)
- 131 Furnace, local heating unit, built-in (Includes built-in humidifiers. Excludes process furnaces, kilns use 353)
- 132 Furnace, central heating unit (Includes built-in humidifiers. Excludes process furnaces, kilns, use 353)
- 133 Boiler (power, process, heating)
- 141 Heaters (Includes floor furnaces, wall heaters, and baseboard heaters. Excludes catalytic heaters (use 142), oil-filled heaters (use 143), hot water heaters (use 152))
- 142 Heaters, catalytic
- 143 Heater, oil filled (Excludes kerosene heaters, use 141)
- 144 Heat lamps
- 145 Heat tape
- 151 Water heater (Includes sink-mounted instant hot water heaters)
- 152 Steam line, heat pipe, hot air duct (Includes radiators and hot water baseboard heaters)
- 100 Heating, ventilation, and air conditioning, other

ELECTRICAL DISTRIBUTION, LIGHTING, AND POWER TRANSFER

- 211 Electrical power utility line (Excludes wires from the utility pole to the structure)
- 212 Electrical service supply wires. Wires from utility pole to meter box
- 213 Electric meter, meter box
- 214 Electrical wiring from meter box to circuit breaker board, fuse box, or panel board
- 215 Panel board (fuse), switchboard, circuit breaker board with or without ground-fault interrupter
- 216 Electrical branch circuit (Includes armored (metallic) cable, nonmetallic sheathing, or wire in conduit)
- 217 Outlet, receptacle (Includes wall-type receptacles, electric dryer and stove receptacles)
- 218 Wall-type switch – includes light switches
- 219 Ground-fault interrupters (GFI), portable, plug-in
- 221 Transformer, low voltage (not more than 50 volts)
- 222 Overcurrent, disconnect equipment (Excludes panel boards)
- 223 Transformer, distribution-type
- 224 Generators
- 225 Inverter
- 226 Uninterrupted power supply (UPS)
- 227 Surge protectors
- 228 Battery chargers, rectifier
- 229 Battery (Includes all battery types)
- 231 Lamp: tabletop, floor desk (Excludes halogen fixtures, use 235, and light bulb use 238)
- 232 Lantern, flashlight
- 233 Incandescent lighting fixtures
- 234 Fluorescent lighting fixtures, ballast
- 235 Halogen lighting fixture or lamp
- 236 Sodium, mercury vapor lighting fixture or lamp
- 237 Portable or movable work light, trouble light
- 238 Light bulbs
- 241 Night light
- 242 Decorative lights, line voltage (Includes holiday lighting, Christmas lights)
- 243 Decorative or landscape lighting, low voltage
- 244 Signs (Include neon signs)
- 251 Fence, electric
- 252 Traffic control devices
- 253 Lightning rod, arrester/grounding device
- 261 Power cords, plug; detachable from appliance

- 262** Power cords, plug; permanently attached to appliance
- 263** Extension cord
- 200** Electrical distribution, lighting, and power transfer, other

SHOP TOOLS AND INDUSTRIAL EQUIPMENT

- 311** Power saw
- 312** Power lathe
- 313** Power shaper, router, jointer, planer
- 314** Power cutting tool
- 315** Power drill, screwdriver
- 316** Power sander, grinder, bugger, polisher
- 317** Power hammer, jackhammer
- 318** Power nail gun, stud driver, stapler
- 321** Paint dipper
- 322** Paint flow coating machine
- 323** Paint mixing machine
- 324** Paint sprayer
- 325** Coating machine (Includes asphalt-saturating and rubber-spreading machines)
- 331** Welding torch (Excludes cutting torches, use 332)
- 332** Cutting torch (Excludes welding torches, use 331)
- 333** Burners (Includes Bunsen burners, plumber furnaces, and blowtorches. Excludes weed burners, use 523)
- 334** Soldering equipment
- 341** Air compressor
- 342** Gas compressor
- 343** Atomizing equipment (Excludes paint spraying equipment, use 324)
- 344** Pump (Excludes pumps integrated with other types of equipment)
- 345** Wet/dry vacuum (shop vacuum)
- 346** Hoist, lift, crane
- 347** Powered jacking equipment (Includes hydraulic rescue tools)
- 348** Drilling machinery or equipment (Includes water or gas drilling equipment)
- 351** Heat-treating equipment
- 352** Incinerator
- 353** Industrial furnace, oven, kiln (Excludes ovens for cooking, use 646)
- 354** Tarpot, tar kettle
- 355** Casting, molding, forging equipment
- 356** Distilling equipment
- 357** Digester, reactor

- 358** Extractor, waste recovery machine (Includes solvent extractors such as used in dry-cleaning operations and garneting equipment)
- 361** Conveyor (Excludes agricultural conveyors, use 513)
- 362** Power transfer equipment: ropes, cables, blocks, belts
- 363** Power takeoff
- 364** Powered valves
- 365** Bearing or brake
- 371** Picking, carding, weaving machines (Includes cotton gins)
- 372** Test equipment
- 373** Gas regulator (Include propane, butane, LP, or natural gas regulators and flexible hose connects to gas appliances)
- 374** Motor, separate (Includes bench motors. Excludes internal combustion motors)
- 375** Internal combustion engines (nonvehicular)
- 377** Car washing equipment

COMMERCIAL AND MEDICAL EQUIPMENT

- 411** Dental, medical, or other powered bed or chair (Includes powered wheelchairs)
- 412** Dental equipment, other
- 413** Dialysis equipment
- 414** Medical imaging equipment (Includes MRI, CAT scan, and ultrasound)
- 415** Medical monitoring equipment
- 416** Oxygen administration equipment
- 417** Radiological equipment, x-ray, radiation therapy
- 418** Sterilizer, medical
- 419** Therapeutic equipment
- 421** Transmitter
- 422** Telephone switching gear, including PBX
- 423** TV monitor array (Includes control panels with multiple monitors and security monitoring stations. Excludes single TV monitoring configurations, use 753)
- 424** Studio-type sound recording modulating equipment (Includes professional studio television cameras. Excludes home camcorders and video equipment, use 756)
- 425** Studio-type sound recording/modulating equipment
- 426** Radar equipment
- 431** Amusement ride equipment
- 432** Ski lift
- 433** Elevator or lift
- 434** Escalator

- 441 Microfilm, microfiche viewing equipment
- 442 Photo processing equipment (Include microfilm processing equipment)
- 443 Venting machine
- 444 Nonvideo arcade game (Includes pinball machines and the like. Excludes electronic video games, use 755)
- 445 Water fountain, water cooler
- 446 Telescope (Includes radio telescopes)
- 451 Electron microscope

GARDEN TOOLS AND AGRICULTURAL EQUIPMENT

- 511 Combine, threshing machine
- 512 Hay processing equipment
- 513 Farm elevator or conveyor
- 514 Silo loader, unloader, screw/sweep auger
- 515 Feed grinder, mixer, blender
- 516 Milking machine
- 517 Pasteurizer
- 518 Cream separator
- 521 Sprayer, farm, or garden
- 522 Chain saw
- 523 Weed burner
- 524 Lawn mower
- 525 Lawn, landscape trimmer, edger
- 531 Lawn vacuum
- 532 Leaf blower
- 533 Mulcher, grinder, chipper (Includes leaf mulcher)
- 534 Snow blower, thrower
- 535 Log splitter
- 536 Post hole auger
- 537 Post driver, pile driver
- 538 Tiller, cultivator

KITCHEN AND COOKING EQUIPMENT

- 611 Blender, juicer, food processor, mixer
- 612 Coffee grinder
- 621 Can opener
- 622 Knife
- 623 Knife sharpener
- 631 Coffee maker or teapot
- 632 Food warmer, hot plate
- 633 Kettle
- 634 Popcorn popper
- 635 Pressure cooker or canner
- 636 Slow cookers
- 637 Toaster, toaster oven, countertop broiler
- 638 Waffle iron, griddle

- 639 Wok, frying pan, skillet
- 641 Bread-making machines
- 642 Deep fryer
- 643 Grill, hibachi, barbeque
- 644 Microwave oven
- 645 Oven, rotisserie
- 646 Range with or without an oven or cooking surface (Includes counter-mounted stoves)
- 647 Steam table, warming drawer/table
- 651 Dishwasher
- 652 Freezer (Standalone, not attached to refrigerator)
- 653 Garbage disposal
- 654 Grease hood/duct exhaust fan
- 655 Ice machine/maker (Standalone, separate from refrigerator)
- 656 Refrigerator, refrigerator/freezer

ELECTRONIC AND OTHER ELECTRICAL EQUIPMENT

- 711 Computer (Excludes external storage devices, use 712)
- 712 Computer storage devices, external (Includes CD-ROM drives, external hard drives. Excludes devices installed inside a computer casing, use 711)
- 713 Computer modem, external (Includes routers)
- 714 Computer monitor
- 715 Computer printer (Includes multifunction machines, i.e. copy/fax/scanner)
- 716 Computer projection device
- 721 Adding machine, calculator
- 722 Telephones, cell phones
- 723 Cash register
- 724 Copier, standalone
- 725 Fax machines
- 726 Paper shredder
- 727 Postage, shipping meter equipment
- 728 Typewriter
- 731 Guitar
- 732 Piano, organ (Excludes synthesizers and musical keyboards, use 733)
- 733 Musical synthesizer or keyboard
- 741 CD player
- 742 DVD players and recorders
- 743 Radio (Excludes two-way radios, use 744)
- 744 Radio, two-way
- 745 Record player, phonograph, turntable
- 747 Speaker, audio – Separate component
- 748 Stereo equipment (Includes receivers, amplifiers, equalizers)

- 749 Tape/audio recorders
- 751 Cable converter box
- 752 Projector: film, slide, overhead
- 753 Television
- 754 VCR or VCR-TV combo
- 755 Video game, electronic
- 756 Camcorder, video camera
- 757 Photographic camera and equipment (Includes digital cameras)

PERSONAL AND HOUSEHOLD EQUIPMENT

- 811 Clothes dryer
- 812 Trash compactor
- 813 Washer/dryer combo (one unit)
- 814 Washing machine, clothes
- 821 Hot tub, whirlpool spa
- 822 Swimming pool equipment
- 831 Broom, electric
- 832 Carpet cleaning equipment (Includes rug shampoos)
- 833 Floor buffer, waver, cleaner
- 834 Vacuum cleaner
- 841 Comb, hairbrush
- 842 Curling iron
- 843 Electrolysis equipment
- 844 Hair curler warmer
- 845 Hair dryer
- 846 Makeup mirror, lighted
- 847 Razor, shaver, electric
- 848 Suntan equipment, sunlamp
- 849 Toothbrush, electric
- 851 Baby bottle warmer
- 852 Blanket, electric
- 853 Heating pad
- 854 Clothes steamer
- 855 Clothes iron
- 861 Automatic door opener (Excludes garage door openers, use 863)
- 862 Burglar alarm
- 863 Garage door opener
- 864 Gas detector
- 865 Intercom
- 866 Smoke or heat detector, fire alarm (Includes control equipment)
- 868 Thermostat
- 871 Ashtray
- 872 Charcoal lighter, utility lighter
- 873 Cigarette lighter, pipe lighter

- 874 Fire-extinguishing equipment (Includes electronic controls)
- 875 Insect trap (Includes bug zappers)
- 876 Timer
- 877 Novelty lighter
- 881 Model vehicles (Include model airplanes, boats, rockets, and powered vehicles used for hobby and recreational purposes)
- 882 Toy, powered
- 883 Woodburning kit
- 891 Clock
- 892 Gun
- 893 Jewelry cleaning machine
- 894 Scissors
- 894 Sewing machine
- 896 Shoe polisher
- 897 Sterilizer, non-medical

****Codes ending in '0' (i.e., 100, 200, 300 etc.) should be used ONLY when other codes don't apply.**

*****Use "undetermined" when without a doubt the Item First Ignited cannot be identified.**



Additional coding questions and/or assistance, please contact (208) 334-4372